



SECTION ET

ET

ENGINE TUNE-UP

CONTENTS

EMISSION CONTROL DEVICES	ET- 2	REPLACING FUEL FILTER	ET- 9
BASIC MECHANICAL SYSTEM	ET- 3	CHECKING AIR LEAKAGE IN AIR INTAKE SYSTEM	ET-10
ADJUSTING INTAKE AND EXHAUST VALVE CLEARANCE	ET- 3	CHECKING VACUUM FITTING TUBES AND CONNECTIONS	ET-11
CHECKING AND ADJUSTING DRIVE BELTS	ET- 3	CHECKING AIR REGULATOR HOSES	ET-11
CHANGING ENGINE OIL	ET- 4	REPLACING AIR CLEANER FILTER	ET-11
REPLACING OIL FILTER	ET- 4	CHECKING CABLE HARNESS AND CONNECTORS	ET-11
CHANGING ENGINE COOLANT	ET- 4	EMISSION CONTROL SYSTEM	ET-11
CHECKING COOLING SYSTEM, HOSES AND CONNECTIONS	ET- 4	REPLACING P.C.V. VALVE	ET-11
CHECKING ENGINE COMPRESSION	ET- 5	CHECKING VENTILATION HOSES	ET-11
IGNITION AND FUEL SYSTEM	ET- 6	CHECKING VAPOR LINES	ET-11
CHECKING BATTERY	ET- 6	REPLACING CARBON CANISTER FILTER	ET-12
CHECKING AND ADJUSTING IGNITION TIMING	ET- 6	SERVICE DATA AND SPECIFICATIONS	ET-13
CHECKING AND REPLACING SPARK PLUGS	ET- 7	INSPECTION AND ADJUSTMENT	ET-13
CHECKING IGNITION WIRING	ET- 7	TIGHTENING TORQUE	ET-14
CHECKING AND ADJUSTING IDLE RPM AND MIXTURE RATIO	ET- 7	TROUBLE DIAGNOSES AND CORRECTIONS	ET-15
CHECKING FUEL LINES	ET- 9	SPECIAL SERVICE TOOLS	ET-22



Note: When turning crankshaft, be sure to use proper timing light system, etc. to avoid any damage to the engine.

EMISSION CONTROL DEVICES

System name	Device	Engine Model	L28					
		Transmission	U.S.A.				Canada	
			Destination		California			
			M/T	A/T	M/T	A/T	M/T	A/T
Engine Proper	Cylinder head exhaust port liner		X	X	X	X	X	X
B.C.D.D.	With altitude corrector		-	-	X	X	-	-
	Without altitude corrector		X	X	-	-	X	X
	Inhibitor switch		-	X	-	X	-	X
	Speed detecting switch		X	-	X	-	X	-
Ignition System	IC Ignition Unit, Distributor (Pick-up coil type)		X	X	X	X	X	X
	V.D.V. (Vacuum delay valve - Spark timing)		-	-	X	X	X	X
E.G.R. System	E.G.R. control valve		X	X	X	X	X	X
	B.P.T. valve		X	X	X	X	-	-
	T.V.V. (Thermal vacuum valve-E.G.R.)		X	X	X	X	X	X
	V.D.V. (Vacuum delay valve - E.G.R.)		-	-	X	X	-	-
Catalytic Converter System	Catalytic converter		-	-	X	X	-	-
Others	Dash pot		X	-	X	-	-	-
	Carbon canister		X	X	X	X	X	X
	Fuel check valve (with vacuum relief valve)		X	X	X	X	X	X
	P.C.V. valve		X	X	X	X	X	X

Remarks:

- X : Available
- : Not available
- M/T : Manual transmission
- A/T : Automatic transmission
- B.C.D.D. : Boost controlled deceleration device
- E.G.R. : Exhaust gas recirculation
- B.P.T. : Back pressure transducer
- P.C.V. : Positive crankcase ventilation

BASIC MECHANICAL SYSTEM

ADJUSTING INTAKE AND EXHAUST VALVE CLEARANCE

Note: Valve clearance adjustment cannot be made while engine is in operation.

1. Start engine and warm up engine until water temperature indicator points to the middle of gauge, then stop engine.

2. Remove valve rocker cover.

3. Loosen pivot lock nut, using Pivot Adjuster ST10640001, and turn valve rocker pivot until specified value is obtained.

Tighten pivot lock nut securely after adjustment, and recheck clearance.




Fig. ET-1 Adjusting Valve Clearance

Valve clearance

		Unit: mm (in)
Hot	Intake	0.25 (0.010)
	Exhaust	0.30 (0.012)

Tightening torque:


Pivot lock nut

5.0 to 6.0 kg-m
(36 to 43 ft-lb)

Order of valve clearance adjustments is as follows:

Note: When turning crankshaft with starter, remove high tension cable from ignition coil, then turn it.

- (1) Set so that high point of No. 1 cam lobe points above. See Fig. ET-2.
- Exhaust valve ① of No. 1 cylinder
 - Intake valve ③ of No. 2 cylinder
 - Exhaust valve ⑦ and intake valve ⑧ of No. 4 cylinder
 - Exhaust valve ⑨ of No. 5 cylinder
 - Intake valve ⑪ of No. 6 cylinder




ET436

Fig. ET-2 Sequence of Adjusting Valve Clearance

- (2) Set so that high point of No. 1 cam lobe points down. See Fig. ET-3.
- Intake valve ② of No. 1 cylinder
 - Exhaust valve ④ of No. 2 cylinder
 - Intake valve ⑤ and exhaust valve ⑥ of No. 3 cylinder

- Intake valve ⑩ of No. 5 cylinder
- Exhaust valve ⑫ of No. 6 cylinder




ET436

Fig. ET-3 Sequence of Adjusting Valve Clearance

CHECKING AND ADJUSTING DRIVE BELTS

1. Check for cracks or damage. Replace if necessary.
2. Normal drive belt deflection is shown in figure below, when moderate force is applied midway between pulleys.

Force: 10 kg (22 lb)



Unit: mm (in)

ET493

Fig. ET-4 Checking Drive Belt for Deflection

CHANGING ENGINE OIL

1. Check if oil is diluted with water or gasoline. Drain and refill oil if necessary.

⊕ Tightening torque:

Oil pan drain plug
2.0 to 3.0 kg-m
(14 to 22 ft-lb)

Note:

- A milky oil indicates the presence of cooling water. Isolate the cause and take corrective measure.
- An oil with extremely low viscosity indicates dilution with gasoline.

2. Check oil level. If below the specified level, raise it up to the H level.

Engine oil capacity:

With oil filter
4.5 liters
(4 1/4 US qt, 4 Imp qt)

Without oil filter
4.0 liters
(4 1/4 US qt, 3 1/2 Imp qt)

REPLACING OIL FILTER

The oil filter is a cartridge type and can be removed using Oil Filter Wrench ST19320000.

Check for oil leaks past gasketed flange. If leakage is found, retighten just enough to stop leakage. If retightening is no longer effective, replace filter as assembly.

Note:

- Install oil filter by tightening by hand.
- Do not overtighten oil filter, lest leakage should occur.

CHANGING ENGINE COOLANT

Whenever coolant is changed, the cooling system must be flushed and refilled with a new coolant. Check the coolant level.

See instructions attached to the anti-freeze container for mixing ratio of anti-freeze to water.

Cooling water capacity


Unit: ℓ (US qt, Imp qt)

With coolant reservoir	10.5 (11 1/4, 9 1/4)
Without coolant reservoir	9.7 (10 1/4, 8 1/2)

Note: The permanent anti-freeze coolant is an ethylene glycol base product containing chemical inhibitors to protect the cooling system from rusting and corrosion. The anti-freeze does not contain any glycerine or ethyl alcohol. It will not evaporate or boil away and can be used with either high or low temperature thermostats. It flows freely, transfers heat efficiently, and will not clog the passages in the cooling system. The anti-freeze must not be mixed with other product. This coolant can be used throughout the seasons of the year.

COOLANT LEVEL

- Without coolant reservoir.



ET462

Fig. ET-5 Coolant Level

The coolant level should be checked and maintained at "A" mm (in) below the bottom of the radiator filler neck.

"A":
20 to 35 mm
(0.79 to 1.38 in)

- With coolant reservoir.



ET463

Fig. ET-6 Coolant Level

Check the amount of coolant in the reservoir tank. If the coolant level is below the MIN. level, remove the reservoir tank filler cap and add enough coolant to reach MAX. level.

CHECKING COOLING SYSTEM, HOSES AND CONNECTIONS

Check hoses and fittings for loose connections or deterioration. Retighten or replace if necessary.

INSPECTION OF RADIATOR CAP

Apply reference pressure 0.9 kg/cm² (13 psi) to radiator cap by means of a cap tester to see if it is satisfactory. Replace cap assembly if necessary.




ET012

Fig. ET-7 Testing Radiator Cap


COOLING SYSTEM PRESSURE TEST

With radiator cap removed, apply reference pressure 1.6 kg/cm² (23 psi) to the cooling system by means of a tester to detect any leakage.



ET464

Fig. ET-8 Cooling System Pressure Test



ET010

Fig. ET-9 Testing Compression Pressure

CHECKING ENGINE COMPRESSION

1. Warm up engine until water temperature indicator points to the middle of gauge.
2. Disconnect all spark plugs.
3. Disconnect cold start valve and all injector connectors.
4. Properly attach a compression tester to spark plug hole in cylinder being tested.

5. Crank engine as quickly as possible.

Compression pressure:

	kg/cm ² (psi)/at rpm
Standard	12.0 (171)/350
Minimum	9.0 (128)/350

6. Cylinder compression in cylinders should not be less than 80% of the highest reading.

If cylinder compression in one or more cylinders is low, pour a small

quantity of engine oil into cylinders through the spark plug holes and retest compression.

- (1) If adding oil helps the compression pressure, the chances are that piston rings are worn or damaged.
- (2) If pressure stays low, the likelihood is that valve is sticking or seating improperly.
- (3) If cylinder compression in any two adjacent cylinders is low, and if adding oil does not help the compression, there is leakage past the gasketed surface.

Oil and water in combustion chambers can result from this problem.



CHECKING IGNITION WIRING

WARNING:
When selector lever is shifted to "D" position, apply parking brake and block both front and rear wheels with chocks.

1. Warm up engine until water temperature indicator points to the middle of gauge.
2. Disconnect cold start valve and all injector connectors.
3. Crank engine two or three times under no-load, then run engine for five minutes.

CHECKING AND ADJUSTING IDLE RPM AND MIXTURE RATIO

Other climates
WARNING
Adjusting idle rpm and mixture ratio should be carried out while the air conditioner is "OFF".
On automatic transmission models, inspection should be carried out while shift lever is in "D" position.

CAUTION:
It becomes necessary to start the engine with a booster battery and jumper cables. The booster battery voltage must not exceed 12 volts.
If the battery cables are disconnected, they should be properly reconnected to the battery terminal to which a good contact is made.

IGNITION AND FUEL SYSTEM

CHECKING BATTERY

1. Remove six vent plugs and check electrolyte level in each battery cell. If necessary, pour distilled water.




Fig. ET-10 Checking Electrolyte Level

2. Measure the specific gravity of battery electrolyte.




Fig. ET-11 Checking Gravity of Battery Electrolyte

Permissible value	Full charge value [at 20°C (68°F)]
Frigid climates	Over 1.22
Other climates	Over 1.20

Note:

- Clean top of battery and terminals with a solution of baking soda and water. Rinse off and dry with compressed air. Top of battery must be clean to prevent current leakage between terminals and from positive terminal to hold-down clamp.
- In addition to current leakage, prolonged accumulation of acid and dirt on top of battery may cause blistering of the material covering connector straps and corrosion of straps.
- After tightening terminals, coat them with petrolatum (vaseline) to protect them from corrosion.

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, the booster battery voltage must not exceed 12 volts, or the control unit of the fuel injection system and other electric components will be damaged.
- If the battery cables are disconnected, they should be tightly clamped to the battery terminals to secure a good contact.

CHECKING AND ADJUSTING IGNITION TIMING

Note:

- On air conditioner equipped models, inspections should be carried out while the air conditioner is "OFF".
- On automatic transmission models, inspections should be carried out while shift lever is in "D" position.

WARNING:

When selector lever is shifted to "D" position, apply parking brake and block both front and rear wheels with chocks.

- Warm up engine until water temperature indicator points to the middle of gauge.
- Race engine two or three times under no-load, then run engine for one minute at idling.
- Check idle speed.

Idle speed:

- Manual Transmission
800 rpm
- Automatic Transmission
(in "D" position)
700 rpm

If necessary, adjust idle speed to the specified rpm by turning idle speed adjusting screw attached to throttle chamber.




Fig. ET-12 Adjusting Idle RPM

4. Check ignition timing with a timing light.

Ignition timing:


- Manual Transmission
10° B.T.D.C./800 rpm
- Automatic Transmission
(in "D" position)
10° B.T.D.C./700 rpm

This operation need not be carried out at 1,000 km (600 mile) service.



Fig. ET-13 Ignition Timing Indicator

If necessary, adjust ignition timing by turning distributor after loosening bolt which secures distributor.




ET487

Fig. ET-14 Adjusting Ignition Timing

CHECKING AND REPLACING SPARK PLUGS

1. Clean plugs in a sand blast cleaner. Inspect each spark plug. Make sure that they are of the specified heat range and type.
2. Inspect insulator for cracks or chips. Check both center and ground electrodes.
3. If they are excessively worn, replace with new spark plugs.
4. Check spark plug gap with plug gap gauge. If not specified value, adjust by bending the ground electrode.



ET073

Fig. ET-15 Checking Spark Plug Gap

Spark plug

For U.S.A.

Type	Standard	B6ES-11 L45W-11 BR6ES-11*
	Hot type	B5ES-11 L46W-11 BR5ES-11*
	Cold type	B7ES-11 L44W-11 BR7ES-11*
Plug gap	mm (in)	1.0 to 1.1 (0.039 to 0.043)

*: Option

For Canada

Type	Standard	BR6ES-11
	Hot type	BR5ES-11
	Cold type	BR7ES-11
Plug gap	mm (in)	1.0 to 1.1 (0.039 to 0.043)

T Tightening torque:
Spark plug

1.5 to 2.0 kg-m
(11 to 14 ft-lb)

CHECKING IGNITION WIRING


Use an ohmmeter to check resistance on high tension cables.

1. Disconnect high tension cables from spark plugs and remove distributor cap.

Note: Do not remove cables from cap.

2. Connect the ohmmeter between cable terminal on the spark plug side and the corresponding electrode inside cap.
3. If the resistance is more than 30,000 ohms, remove cable from cap

and check the cable resistance only. If resistance is still more than 30,000 ohms, replace cable assembly.



EF 125

Fig. ET-16 Checking High Tension Cable

CHECKING AND ADJUSTING IDLE RPM AND MIXTURE RATIO

WARNING:

- a. On automatic transmission models, checks should be performed with the lever shifted to the "D" position. Be sure to engage parking brake and to lock both front and rear wheels with wheel chocks.
- b. Depress brake pedal while accelerating the engine to prevent forward surge of car.
- c. After the adjustment has been made, shift the lever to the "N" or "P" position and remove wheel chocks.

CAUTION:

Before disconnecting and connecting EFI component parts harness connectors, ensure that ignition switch is in "OFF" position.

Note:

- a. On air conditioner equipped models, inspection should be carried out while air conditioner is "OFF".
- b. When checking idle mixture ratio (CO percentage), make sure that the following parts are in good order.
 - Battery
 - Ignition system
 - Engine oil and coolant levels

- Fuses
- EFI component parts
- EFI harness connectors
- Hoses
- Oil filler cap and oil level gauge
- Valve clearance, engine compression

Checking idle mixture requires the use of a CO-meter. When preparing to inspect idle mixture, it is essential to have the meter thoroughly warmed up and calibrated.

1. Warm up engine until water temperature indicator points to the middle of gauge. The procedure to warm up engine is not specifically recommended. Either driving car or operating engine at no load will be good.

2. Make sure that water temperature indicator points to the middle. Further keep engine running at about 2,000 rpm for about 2 minutes without applying load to engine in order to stabilize engine condition. Engine hood should be open.

3. Run engine for about 5 minutes at idling speed.

4. During this 5 minutes, adjust idle speed and ignition timing, referring to Checking and Adjusting Ignition Timing.

5. At about 5 minutes after engine is run, check CO percentage with CO meter.

Idle "CO" %:

California models

0.5% or lower

Non-California models

1.0% or lower


6. If specified idle CO percentage is not obtained, repeat procedures as described in steps 2, 3 and 4 above. Checking idle CO in step 5 can be carried out right after step 4.

If specified idle CO percentage is not obtained, adjust it as described below in the last resort.

(1) Turn ignition switch to "OFF" position.

(2) Disconnect throttle valve switch harness connector.

(3) Connect a lead wire, shown in Fig. ET-17, between terminals No. 24 and No. 30 of throttle valve switch harness connector.



- 1 Air flow meter
- 2 Air by-pass screw
- 3 Throttle chamber
- 4 Throttle valve switch
- 5 Connector of throttle valve switch harness
- 6 Lead wire

ET503

Fig. ET-17 Idle Mixture Ratio Adjustment

Note:


a. The idle mixture ratio of EFI car is set so lean that "CO" % remains almost unchanged when adjustment is made under normal condition. Therefore, when adjusting idle mixture ratio, to distinguish variation in "CO" %, a full enrichment must be temporarily given to idle mixture setting to make it richer.

b. Make lead wire as follows:
Use flat plate terminals 3 mm (0.12 in) wide, 0.8 mm (0.031 in) thick as male terminals. Place flat plate terminals parallel with each other and keep distance between inside faces 2 mm (0.08 in). Solder lead wire to each terminal and wrap insulation tape around soldered portion.

(4) Warm up engine sufficiently, race engine two or three times under no-load, then run engine for one minute at idling speed.

(5) Adjust "CO" % to altitude at measured point by turning air by-pass screw on air flow meter.

Altitude	Idle CO % (full enrichment)
0 to 600 m (0 to 2,000 ft)	3.3%
600 to 1,200 m * (2,000 to 4,000 ft)	4.7%
1,200 to 1,800 m (4,000 to 6,000 ft)	5.7%
Above 1,800 m (6,000 ft)	6.7%



- 1 Air flow meter
- 2 Air by-pass screw

ET465

Fig. ET-18 Adjusting "CO" %

Note:


- a. Air by-pass screw:
Turning counterclockwise – Leaner
Turning clockwise – Richer
- b. When adjusting "CO" %, remove blind plug from air by-pass screw. After adjustment, install the plug on air flow meter.

- (6) Stop engine and remove lead wire and connect connector back to throttle valve switch.
- (7) Check idle speed. If necessary, adjust it to specifications.
- (8) Check "CO%" if it is within specifications.

CHECKING FUEL LINES

Check fuel line for leaks, particularly around connection of fuel pipe and fuel hose.

Retighten loose connections and replace any damaged or deformed parts.



- 1 Fuel pump
- 2 Fuel damper
- 3 Fuel filter
- 4 Injector
- 5 Pressure regulator
- 6 Cold start valve

Fig. ET-19 Fuel Line

CAUTION:

- a. Do not reuse fuel hose clamps after loosening.
- b. Tighten high pressure rubber hose clamp so that clamp end is 3 mm (0.12 in) from hose end or screw position (wider than other portions of clamp) is flush with hose end. Tightening torque specifications are the same for all rubber hose clamps.

Tightening torque of fuel hose clamps:

0.10 to 0.15 kg-m
(0.7 to 1.1 ft-lb)

REPLACING FUEL FILTER

The fuel filter is designed especially for use with the EFI system. It should be replaced as an assembly.

1. Follow the procedure below to decrease fuel pressure to zero.

CAUTION:


Before disconnecting fuel hose, release fuel pressure from fuel line to avoid danger.

- (1) Disconnect ground cable from battery.
- (2) Disconnect cold start valve harness connector.
- (3) Using two jumper wires, connect each terminal to cold start valve connector. See Fig. ET-20.

CAUTION:

Be careful to keep both terminals separate in order to avoid short circuit.

- (4) Release pressure in fuel system by connecting other terminals of jumper wires to battery positive and negative terminals for a few seconds.



EF212A

Fig. ET-20 Releasing Pressure in Fuel System

2. Unfasten clamps securing fuel hoses to the outlet and inlet sides of fuel filter, and disconnect fuel hoses.

Note: Be careful not to spill fuel over engine compartment. Place a rag to absorb fuel.

3. Loosen bolt securing fuel filter to bracket, and remove fuel filter.




Fig. ET-21 Fuel Filter

4. To install fuel filter, reverse the order of removal.

CAUTION:

- a. Do not reuse fuel hose clamps after loosening.
- b. Tighten high pressure rubber hose clamp so that clamp end is 3 mm (0.12 in) from hose end or screw position (wider than other portions of clamp) is flush with hose end.

Tightening torque of fuel hose clamps:

0.10 to 0.15 kg-m
(0.7 to 1.1 ft-lb)

CHECKING AIR LEAKAGE IN AIR INTAKE SYSTEM


Make sure that even a slight air leak does not occur.

When inspecting the EFI system, pay particular attention to hose con-

nections, dipstick, oil filler cap, etc. for any indication of air leaks.

Note: The air flow meter used in the EFI system directly measures the quantity of intake air to permit the supply of the optimum fuel quantity for each cylinder.

- | | |
|--|---|
| 1 Air cleaner filter | 11 Hose (Air regulator to throttle chamber) |
| 2 Air duct (Air cleaner to A.F.M.) | 12 Hose (Throttle chamber to rocker cover) |
| 3 Air flow meter | 13 Cold start valve |
| 4 Air duct (A.F.M. to throttle chamber) | 14 Canister purge line |
| 5 Throttle chamber | 15 Hose (Intake manifold to pressure regulator) |
| 6 Intake manifold | 16 Hose (F.I.C.D. actuator to vacuum tank) |
| 7 Hose (Air duct to air regulator pipe) | 17 Hose (F.I.C.D. actuator to air regulator pipe) |
| 8 Air regulator pipe | 18 F.I.C.D. actuator |
| 9 Hose (Air regulator pipe to air regulator) | 19 Vacuum line (For automatic transmission, air conditioner and A.S.C.D.) |
| 10 Air regulator | |



- | | | |
|--|---|---------------------------------------|
| 20 Brake booster hose | 38 Hose (E.G.R. control valve to 3-way connector) | } Canada models |
| 21 E.G.R. control valve mounting surface | 39 3-way connector | |
| 22 P.C.V. valve | 40 Hose (3-way connector to T.V.V.) | |
| 23 Hose (P.C.V. valve to cylinder block) | 41 Hose (3-way connector to air regulator pipe) | } California and Canada models |
| 24 Hose (Throttle chamber to T.V.V.) | 42 Distributor | |
| 25 Hose (Throttle chamber to 3-way connector) | 43 Hose (Distributor to V.D.V.) | } California models |
| 26 Fuel injector | 44 V.D.V. | |
| 27 Oil seal (on front and rear of crankshaft) | 45 Hose (V.D.V. to 3-way connector) | } Non-California models except Canada |
| 28 Oil pan gasket | 46 Hose (Distributor to 3-way connector) - | |
| 29 Oil level gauge | 47 3-way connector | } |
| 30 E.G.R. control valve | 48 Hose (3-way connector to canister) | |
| 31 Hose (E.G.R. control valve to B.P.T. valve) | 49 Canister | |
| 32 B.P.T. valve | | |
| 33 Hose (B.P.T. valve to V.D.V.) | | |
| 34 V.D.V. | | |
| 35 Hose (V.D.V. to T.V.V.) | | |
| 36 Hose (B.P.T. valve to T.V.V.) - Non-California models except Canada | | |
| 37 Thermal vacuum valve | | |

Fig. ET-22 Checking Air Leakage in Air Intake System

CHECKING VACUUM FITTING TUBES AND CONNECTIONS

Check fittings and hoses for loose connections or damage. Retighten loose parts or replace parts that are not suitable for further use. See Fig. ET-22.

CHECKING AIR REGULATOR HOSES

Check air regulator hoses for leakage, cracks and deterioration. Retighten loose connections and replace any parts if they are damaged or deformed. See Fig. ET-22.

REPLACING AIR CLEANER FILTER

Note: The viscous paper type air cleaner filter does not require any cleaning operation between renewals.




Fig. ET-23 Air Cleaner Filter

CAUTION:

Brushing or blasting operation can cause a clogged filter. This in turn reduces air intake efficiency, resulting in poor engine performance.

Remove air cleaner cover and remove air cleaner filter.

CHECKING CABLE HARNESS AND CONNECTORS

Check harness connectors for correct insertion and harness connector terminals for deformation or rust. Replace faulty parts.

EMISSION CONTROL SYSTEM

REPLACING P.C.V. VALVE

Check P.C.V. valve in accordance with the following method.

With engine running at idle, remove

the ventilator hose from P.C.V. valve. If the valve is working, a hissing noise will be heard as air passes through the valve and a strong vacuum should be felt immediately when a finger is placed over valve inlet.

CHECKING VENTILATION HOSES


1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air.

If any hose cannot be free of obstructions, replace.

Ensure that flame arrester is surely inserted in hose between throttle chamber and rocker cover.

CHECKING VAPOR LINES

1. Check all hoses and fuel tank filler cap.
2. Disconnect vapor vent line connecting carbon canister to check valve.
3. Connect a 3-way connector, a manometer and a cock (or an equivalent 3-way charge cock) to the end of the vent line.
4. Supply fresh air into the vapor vent line through the cock little by little until pressure becomes 400 mmH₂O (15.75 inH₂O).



- | | | |
|---------------|-------------------|--------------------|
| ⇨ Fresh air | 1 Seal rubber | 6 Throttle chamber |
| ⇨ Blow-by gas | 2 Oil level gauge | 7 P.C.V. valve |
| | 3 Baffle plate | 8 Steel net |
| | 4 Oil filler cap | 9 Baffle plate |
| | 5 Flame arrester | |

ET469

Fig. ET-24 Crankcase Emission Control System

5. Shut the cock completely and leave it unattended.
6. After 2.5 minutes, measure the height of the liquid in the manometer.
7. Variation in height should remain with 25 mmH₂O (0.98 inH₂O).
8. When filler cap does not close completely, the height should drop to zero in a short time.
9. If the height does not drop to zero in a short time when filler cap is

removed, it is the cause of a stuffy hose.

Note:

In case the vent line is stuffy, the breathing in fuel tank is not thoroughly made, thus causing insufficient delivery of fuel to engine or vapor lock. It must, therefore, be repaired or replaced.





Fig. ET-25 Checking Evaporative Emission Control System

REPLACING CARBON CANISTER FILTER

Check for a contaminated filter.

Remove canister tray and remove filter at bottom of canister.



EC373A

Fig. ET-26 Replacing Carbon Canister Filter

Note:

Sealant has been applied to contact surface of canister and canister tray. When removing canister tray, pull it off while twisting. When reinstalling canister tray, apply sealant to contact surface of canister and canister tray.

SERVICE DATA AND SPECIFICATIONS

INSPECTION AND ADJUSTMENT

BASIC MECHANICAL SYSTEM

Valve clearance			
Hot	Intake	mm (in)	0.25 (0.010)
	Exhaust	mm (in)	0.30 (0.012)
Drive belt deflection			
Fan, Air conditioner compressor, and Power steering oil pump		mm (in)	8 to 12 (0.31 to 0.47)
Applied pressed force		kg (lb)	10 (22)
Engine oil capacity			
With oil filter		liters (US qt, Imp qt)	4.5 (4 ¾, 4)
Without oil filter		liters (US qt, Imp qt)	4.0 (4 ¼, 3 ¾)
Cooling water capacity			
With coolant reservoir		liters (US qt, Imp qt)	10.5 (11 ½, 9 ¾)
Without coolant reservoir		liters (US qt, Imp qt)	9.7 (10 ¼, 8 ½)
Radiator cap relief pressure		kg/cm ² (psi)	0.9 (13)
Cooling system leakage testing pressure		kg/cm ² (psi)	1.6 (23)
Compression pressure		kg/cm ² (psi)/rpm	
Standard		12.0 (171)/350
Minimum		9.0 (128)/350

Note: Fuel hose clamping position

ABCC-13

Engine Tune-up

IGNITION AND FUEL SYSTEM

Battery electrolyte gravity at 20°C (68°F)

Frigid climates	1.28
Other climates	1.26
Spark plug	

	Type			Plug gap mm (in)
	Standard	Hot type	Cold type	
For U.S.A.	B6ES-11 L45W-11 BR6ES-11*	B5ES-11 L46W-11 BR5ES-11*	B7ES-11 L44W-11 BR7ES-11*	1.0 to 1.1 (0.039 to 0.043)
For Canada	BR6ES-11	BR5ES-11	BR7ES-11	

*Option


Ignition timing and idling speed

Manual transmission	degree/rpm	10° B.T.D.C./800
Automatic transmission (in "D" position)	degree/rpm	10° B.T.D.C./700
"CO" % at idling speed		
California models	%	0.5 or lower
Non-California models	%	1.0 or lower

TIGHTENING TORQUE

Pivot lock nut	kg-m (ft-lb)	5.0 to 6.0 (36 to 43)
Spark plug	kg-m (ft-lb)	1.5 to 2.0 (11 to 14)
Fuel hose clamp	kg-m (ft-lb)	0.10 to 0.15 (0.7 to 1.1)

Note: Fuel hose clamping position



TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
CANNOT CRANK ENGINE OR SLOW CRANKING	Improper grade oil. Partially discharged battery. Malfunctioning battery. Loose fan belt. Trouble in charging system. Wiring connection trouble in starting circuit. Malfunctioning ignition switch. Malfunctioning starting motor.	Replace with proper grade oil. Charge battery. Replace. Adjust. Inspect. Correct. Repair or replace. Repair or replace.
(Trouble-shooting procedure on starting circuit) Switch on the starting motor with head lights "ON".		
When head lights go off or dim considerably, <ol style="list-style-type: none"> Check battery. Check connection and cable. Check starting motor. 		
When head lights stay bright, <ol style="list-style-type: none"> Check wiring connection between battery and starting motor. Check ignition switch. Check starting motor. 		
ENGINE WILL CRANK NORMALLY BUT WILL NOT START		
In this case, the following trouble causes may exist, but in many cases ignition system or fuel system is in trouble.		
<i>Ignition system in trouble</i> <i>Fuel system in trouble</i> <i>Valve mechanism does not work properly</i> <i>Low compression</i>	For inspection procedure for electronic fuel injection system, refer to Engine Fuel section.	
(Trouble-shooting procedure)		
Check spark plug firstly by following procedure. Disconnect high tension cable from one spark plug and hold it about 10 mm (0.39 in) from the engine metal part and crank the engine.		
Good spark occurs.	<ol style="list-style-type: none"> Check spark plug. Check ignition timing. Check fuel system. Check revolution trigger signal. Check cylinder compression. 	Check the current flow in primary circuit. Inspect primary circuit for short. Check distributor pick-up coil operation. Check IC ignition system.
No spark occurs.	Very high current.	

Engine Tune-up

Condition	Probable cause	Corrective action	
Ignition system in trouble	Low or no current.	Check for loose terminal or disconnection in primary circuit.	
		Check for burned points.	
	Malfunctioning distributor pick-up coil.	Replace.	
	Improper air gap.	Adjust.	
	Leak at rotor cap and rotor.	Clean or replace.	
	Malfunctioning spark plug.	Clean, adjust plug gap or replace.	
	Improper ignition timing.	Adjust.	
	Malfunctioning ignition coil.	Replace.	
ENGINE CRANKS NORMALLY BUT WILL NOT START	Disconnection of high tension cable.	Replace.	
	Loose connection or disconnection in primary circuit.	Repair or replace.	
	Irregular revolution trigger pulse.	Replace IC ignition unit.	
	Malfunctioning IC ignition unit.	Replace.	
	Fuel system malfunction	Lack of fuel.	Supply.
		Damaged electronic fuel injection harness or relay.	Replace.
		Malfunctioning fuel pump (Listen to operating sound).	Replace.
		Damaged control unit.	Replace.
Seized injector (Listen to operating sound).		Replace.	
Seized cold start valve.		Replace.	
Malfunctioning air flow meter.		Replace.	
Damaged water temp. sensor.		Replace.	
Malfunctioning pressure regulator.		Replace.	
Dirty fuel filter.		Replace.	
Low compression	Dirty or clogged fuel pipe.	Clean.	
	Clogged fuel tank breather pipe.	Repair and clean.	
	Incorrect spark plug tightening or damaged gasket.	Tighten to normal torque or replace gasket.	
	Improper grade engine oil or low viscosity.	Replace with proper grade oil.	
	Incorrect valve clearance.	Adjust.	
	Compression leak from valve seat.	Lap valves.	
	Sticky valve stem.	Correct or replace valve and valve guide.	
	Weak or damaged valve springs.	Replace valve springs.	
	Compression leak at cylinder head gasket.	Replace gasket.	

ENGINE WILL CRANK NORMALLY BUT WILL NOT START

For inspection procedures for electronic fuel injection system components, refer to Engine Fuel section.

Engine Tune-up

Condition	Probable cause	Corrective action
<p>Low compression</p> <p>(Trouble shooting procedure) Pour the engine oil from plug hole, and then measure cylinder compression.</p> <p>Compression increases.</p> <p>Compression does not change.</p>	<p>Sticking or defective piston ring.</p> <p>Worn piston ring or cylinder.</p>	<p>Replace piston rings.</p> <p>Overhaul engine.</p> <p>Trouble in cylinder or piston ring.</p> <p>Compression leaks from valve, cylinder head or head gasket.</p>
<p>UNSTABLE ENGINE IDLING</p> <p>Ignition system</p> <p>Engine mechanical system in trouble</p> <p>Fuel system malfunction</p> <p>Others</p>	<p>Incorrect idle adjustment</p> <p>Malfunctioning ignition system (spark plug, high tension cable, distributor, IC ignition unit, ignition coil, etc.)</p> <p>Incorrect basic ignition timing.</p> <p>Loose manifold and cylinder head bolts.</p> <p>Incorrect valve clearance.</p> <p>Clogged air cleaner filter.</p> <p>Damaged manifold gaskets.</p> <p>Intake air leakage at following points: Dipstick Oil filler cap Blow-by hoses Intake air duct—air flow meter to throttle chamber, etc.</p> <p>Damaged electronic fuel injection harness.</p> <p>Seized injector (Listen to operating sound).</p> <p>Malfunctioning air regulator (During warm-up driving only)</p> <p>Damaged control unit.</p> <p>Damaged water and air temp. sensor.</p> <p>Malfunctioning throttle valve switch.</p> <p>Irregular fuel pressure.</p> <p>Malfunctioning E.G.R. control system.</p>	<p>Adjust.</p> <p>Replace.</p> <p>Adjust.</p> <p>Retighten bolts.</p> <p>Adjust.</p> <p>Replace filter.</p> <p>Replace gasket.</p> <p>Repair or replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Replace.</p> <p>Repair or replace.</p> <p>Replace pressure regulator.</p> <p>Clean or replace.</p>
<p>HIGH ENGINE IDLE SPEED</p>	<p>Dragged accelerator linkage.</p> <p>Malfunctioning B.C.D.D. system.</p> <p>Malfunctioning air regulator.</p>	<p>Check and correct accelerator linkage.</p> <p>If engine idling speed rises above 1,800 to 2,000 rpm, the cause may be a malfunctioning B.C.D.D. system.</p> <p>Check B.C.D.D. system.</p> <p>Repair or replace if necessary.</p> <p>Replace.</p> <p>For inspection procedures for air regulator, refer to Engine Fuel section.</p>

For inspection procedures for electronic fuel injection system components, refer to Engine Fuel Section.

Engine Tune-up

Condition	Probable cause	Corrective action
HIGH ENGINE IDLE SPEED	<p>Incorrect adjustment of idle speed adjusting screw.</p> <p>Throttle valve is opened excessively at idle.</p> <p>Malfunctioning F.I.C.D.</p>	<p>Correct.</p> <p>Replace throttle chamber.</p> <p>Replace.</p>
ENGINE POWER NOT UP TO NORMAL		Previously mentioned.
Low compression		
Ignition system in trouble	<p>Incorrect ignition timing.</p> <p>Malfunctioning spark plugs.</p> <p>Malfunctioning distributor pick-up coil.</p>	<p>Adjust.</p> <p>Clean, adjust or replace plugs.</p> <p>Replace.</p>
ENGINE POWER BELOW NORMAL		For inspection procedures for electronic fuel injection system components, refer to Engine Fuel Section.
Fuel system malfunction	<p>Throttle valve does not open fully.</p> <p>Damaged electronic fuel injection harness.</p> <p>Seized injector (Listen to operating sound).</p> <p>Malfunctioning air flow meter.</p> <p>Malfunctioning throttle valve switch.</p> <p>Irregular fuel pressure.</p> <p>Clogged fuel pipe.</p> <p>Dirty or clogged fuel filter.</p> <p>Fuel pump will not work properly.</p>	<p>Adjust.</p> <p>Replace.</p> <p>Replace.</p> <p>Repair or replace.</p> <p>Replace pressure regulator if necessary.</p> <p>Replace if necessary.</p> <p>Replace.</p> <p>Replace.</p>
Air intake system malfunction	<p>Clogged air cleaner filter.</p> <p>Air leaking from manifold gasket.</p> <p>Intake air leakage at following points:</p> <ul style="list-style-type: none"> Dipstick Oil filler cap Blow-by hoses Intake air duct—air flow meter to throttle chamber etc. 	<p>Replace filter.</p> <p>Replace gasket.</p> <p>Repair or replace.</p>
Overheating	<p>Insufficient coolant.</p> <p>Loose fan belt.</p> <p>Worn or damaged fan belt.</p> <p>Malfunctioning thermostat.</p> <p>Malfunctioning water pump.</p> <p>Clogged or leaky radiator.</p> <p>Malfunctioning radiator filler cap.</p> <p>Air in cooling system.</p> <p>Improper engine oil grade.</p> <p>Incorrect ignition timing.</p> <p>Malfunctioning thermal vacuum valve (for E.G.R. system).</p>	<p>Replenish.</p> <p>Adjust fan belt.</p> <p>Replace.</p> <p>Replace.</p> <p>Flush, repair or replace.</p> <p>Replace.</p> <p>Retighten each part of cooling system.</p> <p>Replace with proper grade oil.</p> <p>Adjust.</p> <p>Replace.</p>

Engine Tune-up

Condition	Probable cause	Corrective action
<p>Overcooling</p> <p>Others</p>	<p>Malfunctioning thermostat.</p> <p>Improper octane fuel.</p> <p>Improper tire pressure.</p> <p>Dragging brake.</p> <p>Clutch slipping.</p>	<p>Replace.</p> <p>Replace with specified octane fuel.</p> <p>Inflate to specified pressure.</p> <p>Adjust.</p> <p>Adjust.</p>
<p>NOISY ENGINE</p> <p>Car knocking</p> <p>Mechanical knocking</p> <p>Crankshaft bearing knocking.</p> <p>Connecting rod bearing knocking.</p> <p>Piston and cylinder noise.</p> <p>Piston pin noise.</p> <p>Water pump noise.</p> <p>Others.</p>	<p>Overloaded engine.</p> <p>Carbon knocking.</p> <p>Timing knocking.</p> <p>Fuel knocking.</p> <p>Preignition (misusing of spark plug).</p> <p>This strong dull noise increases when engine is accelerated. To locate the place, cause a misfire on each cylinder. If the noise stops by the misfire, this cylinder generates the noise.</p> <p>This is a little higher-pitched noise than the crankshaft knocking, and also increases when engine is accelerated. Cause a misfire on each cylinder and if the noise diminishes almost completely, this crankshaft bearing generates the noise.</p> <p>When you hear an overlapping metallic noise which increases its magnitude with the revolution of engine and which decreases as engine is warmed up, this noise is caused by piston and cylinder. To locate the place, cause a misfire on each cylinder.</p> <p>This noise is heard at each highest and lowest dead end of piston. To locate the place, cause a misfire on each cylinder.</p> <p>This noise may be caused by worn or damaged bearings, or by the uneven surface of sliding parts.</p> <p>An improper adjustment of valve clearance.</p> <p>Noise of timing chain.</p> <p>An excessive end-play on crankshaft.</p>	<p>Use right gear in driving.</p> <p>Disassemble cylinder head and remove carbon.</p> <p>Adjust ignition timing.</p> <p>Use specified octane fuel.</p> <p>Use specified spark plug.</p> <p>This is caused by worn or damaged bearings, or unevenly worn crankshaft. Renew bearings and adjust or change crankshaft. Check lubrication system.</p> <p>Same as the case of crankshaft bearings.</p> <p>This may cause an abnormal wearing of cylinder and lower compression which in turn will cause a lower out-put power and excessive consumption of oil.</p> <p>Overhaul engine.</p> <p>This may cause a wear on piston pin, or piston pin hole.</p> <p>Renew piston and piston pin assembly.</p> <p>Replace water pump with a new one.</p> <p>Adjust.</p> <p>Adjust the tension of chain.</p> <p>Disassemble engine and renew main bearing.</p>

Engine Tune-up

Condition	Probable cause	Corrective action
<p>Others.</p>	<p>Note: This noise will be heard when clutch is disengaged.</p> <p>Wear on clutch pilot bushing.</p>	<p>Renew bushing and adjust drive shaft.</p>
<p>ABNORMAL COMBUSTION (backfire, after fire run-on etc.)</p> <p>Improper ignition timing</p> <p>Fuel stem malfunction</p> <p>Defective cylinder head, etc.</p> <p>Others</p>	<p>Note: This noise will be heard when clutch is disengaged.</p> <p>Improper ignition timing.</p> <p>Improper heat range of spark plugs.</p> <p>Intake air leakage at following points: Dipstick Oil filler cap Blow-by hoses Intake air duct—air flow meter to throttle chamber etc.</p> <p>Damaged electronic fuel injection harness.</p> <p>Damaged control unit.</p> <p>Malfunctioning air flow meter.</p> <p>Damaged water temp. sensor.</p> <p>Improperly adjusted valve clearance.</p> <p>Excess carbon in combustion chamber.</p> <p>Damaged valve spring (backfire, after fire).</p> <p>Malfunctioning E.G.R. control system.</p>	<p>Adjust ignition timing.</p> <p>Use specified spark plugs.</p> <p>Repair or replace.</p> <p>Replace. } For inspection procedures for electronic fuel injection system components, refer to Engine Fuel Section.</p> <p>Replace. }</p> <p>Replace. }</p> <p>Replace. }</p> <p>Adjust.</p> <p>Remove head and get rid of carbon.</p> <p>Replace it with a new one.</p> <p>Check for loose vacuum hoses. Replace if necessary.</p> <p>Replace.</p>
<p>EXCESSIVE OIL CONSUMPTION</p> <p>Oil leakage</p>	<p>Loose oil drain plug.</p> <p>Loose or damaged oil pan gasket.</p> <p>Loose or damaged chain cover gasket.</p> <p>Damaged oil seal in front and rear of crankshaft.</p> <p>Loose or damaged rocker cover gasket.</p> <p>Improper tightening of oil filter.</p> <p>Loose or damaged oil pressure switch.</p>	<p>Tighten it.</p> <p>Renew gasket or tighten it.</p> <p>Renew gasket or tighten it.</p> <p>Renew oil seal.</p> <p>Renew gasket or tighten it (but not too much).</p> <p>Renew gasket and tighten it with the proper torque.</p> <p>Renew oil pressure switch or tighten it.</p>



Engine Tune-up

Condition	Probable cause	Corrective action
<p>Excessive oil consumption</p> <p>Others</p>	<p>Cylinder and piston wear.</p> <p>Improper location of piston ring or reversely assembled piston ring.</p> <p>Damaged piston rings.</p> <p>Worn piston ring groove and ring.</p> <p>Fatigue of valve oil seal lip.</p> <p>Worn valve stem.</p> <p>Inadequate quality of engine oil.</p> <p>Engine overheat.</p>	<p>Overhaul cylinder and renew piston.</p> <p>Remount piston rings.</p> <p>Renew rings.</p> <p>Repair or renew piston and cylinder.</p> <p>Renew piston and piston ring.</p> <p>Replace seal lip with a new one.</p> <p>Renew valve or guide.</p> <p>Use the designated oil.</p> <p>Previously mentioned.</p>
<p>POOR FUEL ECONOMY</p> <p>Ignition system</p> <p>See the explanation of the power decrease</p>		
<p>Others</p> <p>Emission control system</p> <p>Fuel system malfunction</p>	<p>Exceeding idling revolution.</p> <p>Malfunctioning E.G.R. control system.</p> <p>Fuel leakage.</p> <p>Damaged electronic fuel injection harness.</p> <p>Damaged control unit.</p> <p>Malfunctioning air flow meter.</p> <p>Damaged air temperature sensor.</p> <p>Malfunctioning throttle valve switch.</p> <p>Fuel leakage at injector or cold start valve.</p> <p>Fuel leakage at rubber fuel hose.</p> <p>Irregular fuel pressure.</p>	<p>Adjust it to the designated rpm.</p> <p>Repair or tighten the connection of fuel pipes.</p> <p>Replace.</p> <p>Repair or replace.</p> <p>Replace. } For inspection procedures for electronic fuel injection system components, refer to Engine Fuel Section.</p> <p>Replace. }</p> <p>Replace. }</p> <p>Replace. }</p> <p>Replace. }</p> <p>Replace damaged part.</p> <p>Repair or replace.</p> <p>Replace pressure regulator if necessary.</p>
<p>TROUBLE IN OTHER FUNCTIONS</p> <p>Decreased oil pressure</p>	<p>Inadequate oil quality.</p> <p>Overheat.</p> <p>Malfunctioning oil pump regulator valve.</p> <p>Functional deterioration of oil pump.</p> <p>Blocked oil filter.</p>	<p>Use the designated oil.</p> <p>Previously mentioned.</p> <p>Disassemble oil pump and repair or renew it.</p> <p>Repair or replace it with a new one.</p> <p>Renew it.</p>

Engine Tune-up

Condition	Probable cause	Corrective action
Decreased oil pressure	Increased clearance in various sliding parts. Blocked oil strainer. Malfunctioning oil gauge pressure switch.	Disassemble and replace the worn parts with new ones. Clean it. Replace it with a new one.
Excessive wear on the sliding parts	Oil pressure decreases. Damaged quality or contamination of oil. Air leakage from air intake duct. Damaged air cleaner. Overheat or overcool.	Previously mentioned. Change the oil with proper one and element. Repair or replace. Change element. Previously mentioned.
Scuffing of sliding parts	Improper fuel mixture. Decrease of oil pressure. Insufficient clearances. Overheat. Improper fuel mixture.	Check the fuel system. Previously mentioned. Readjust to the designated clearances. Previously mentioned. Check the fuel system.

SPECIAL SERVICE TOOLS

Tool number & tool name	Kent-Moore No.	Tool number & tool name	Kent-Moore No.
	Reference page or Fig. No.		Reference page or Fig. No.
ST10640001 Pivot adjuster	J 25615-01	ST19320000 Oil filter wrench	J 25664
	Fig. ET-1		Page ET-4